




Air Power Systems Co., Inc.  
8178 E. 44<sup>th</sup> St.  
Tulsa, OK 74145  
(918) 622-5600 FAX: (918) 622-5469  
Web: www.apscopower.com

## APSCO V-5-B Installation Instructions

Rev.: )E, 06/21/18  
Approved By: Ryan Tietz  
II #: II-151

Page 1 of 1



### Installation:

1. Install air line from the "RAISE/TIP" Port of the Cab Control to the Inlet Port of the V-5-B. Run the Outlet Port air line from the V-5-B Outlet Port to the "RAISE/TIP" Port on the Air Cylinder on the Dump Pump.  
**Note: Apply thread sealant to all fittings.**
2. Raise Dump Body to desired height.
3. Tie cable to Spring and Dump Body. **Note: Insure that V-5-B Spring is in its relaxed position (ie there is no tension on Spring).**

### Plumbing Diagram

